

How to use Garmin eTrex 10 to find a waypoint



1. Turn on by pressing Power button



2. Select Waypoints by using the Navigation button (circled)



3. Select desired Waypoint from list by scrolling and then pushing in the Navigation button



4. Select "Go"



5. Map will appear on screen



6. Press "back" to get to the main menu, then open the "Compass" feature



7. Compass tells you the direction to your destination and distance to destination.